7. Shut-off and dosage valves



Shut-off valves are required were gas or liquid mediums are used. Here we have the possibility stop the flow at any position in the piping system. Often it is required that a certain dosage of the medium is needed. This is done through changing the cross-section between the spindle and cone.

Contents

E07.01.01 Shut-off valve AV6

E07.01.02 Double shut-off valve DV5

E07.01.04 Shut-off valve AV4

E07.02.01 Fine dosage valve "Rossignol"

E07.02.02 Flowmeter